




## Device Layout



## Charge and Power On Your Device



Remember to fully charge your battery before use.

**NOTE:** Your device is always on when being charged.

To turn your device on or off, press and hold the **Power/Lock Key** ①.



## Google Account Set-up

When you turn your device on for the first time, you will be prompted to set up your existing Gmail account. If you don't have one, you can create one. Touch the **Android** to start the process.



Now your Gmail™, Google contacts, and Google calendar events will all be loaded to your device automatically.

Use the area below to record your Google account information for future reference.

Username: \_\_\_\_\_@gmail.com

Password: \_\_\_\_\_

## Touch Screen Tips

There are several touch motions recognized by the device:

**Touch** – to select a menu item or open an application

**Touch and hold** – to grab an object that you want to move or open an option menu

**Drag** – to move an object or scroll slowly on a list or web page

**Flick** – to scroll quickly on a list or web page (touch the screen again to stop the scrolling action)

**Double tap** – to zoom in/out on a web page or picture

## Notifications


Notifications let you know when an event has occurred that may require your attention such as voicemail, missed calls, text messages, etc.

To view your notifications, touch the status bar at the top of the screen and drag it down. Touch each notification to view the details. When you are done, touch the **Home Key** to return to the home screen.



## Lock and Unlock Screen


Your display will go dark if untouched for a period of time. Press the **Power/Lock Key** ① to wake it up again. This lock screen will appear.



To unlock the screen, touch the unlock icon and drag it to the right.


## Home Screen

Your home screen has 3 panels. Touch the **Home Key** to go to the home screen.



## Applications Tab

From the home screen, touch the **Applications button** to open the Applications tab. Open an application simply by touching it.



**View or change your device settings** such as call ringtone, screen timeout, Wi-Fi, Bluetooth, location and security management.